


SYSTEM DIAGRAM (After '99)



(1)	Engine stop relay	(18)	PAIR check valve
(2)	Main fuse B (30A)	(19)	Knock sensor
(3)	Engine stop switch	(20)	ECT sensor
(4)	Sub-fuse (10A)	(21)	Ignition pulse generator
(5)	Ignition switch	(22)	O ₂ Sensor (California type only)
(6)	Main fuse A (30A)	(23)	Water temperature meter
(7)	Bank angle sensor	(24)	Fuel cut-off relay
(8)	Sub-fuse (10A)	(25)	Fuel pump
(9)	Battery	(26)	Vehicle speed sensor
(10)	Pressure regulator	(27)	Neutral switch
(11)	IAT sensor	(28)	Clutch switch
(12)	Spark plug	(29)	Side stand switch
(13)	PAIR solenoid valve	(30)	Malfunction indicator
(14)	TP sensor	(31)	Service check connector
(15)	MAP sensor	(32)	Tachometer
(16)	Injector	(33)	Purge control solenoid valve (California type only)
(17)	Cam pulse generator	(34)	EVAP canister (California type only)