


Install the handlebar stopper ring.  
Install the pre-load adjuster and stopper ring.




**INSTALLATION**

Install the fork leg through the bottom bridge, handlebar and top bridge (page 14-44).  
Position the top end of the fork slider flush with the upper surface of the top bridge as shown.



Tighten the bottom bridge pinch bolts to the specified torque.

**TORQUE: 23 N·m (2.3 kgf·m, 17 lbf·ft)**



If the fork bolt was loosened, tighten it to the specified torque.

**TORQUE: 34 N·m (3.5 kgf·m, 25 lbf·ft)**

Tighten the top bridge pinch bolt to the specified torque.

**TORQUE: 23 N·m (2.3 kgf·m, 17 lbf·ft)**

Tighten the handlebar pinch bolt to the specified torque.

**TORQUE: 26 N·m (2.7 kgf·m, 20 lbf·ft)**

Install the following:

- Front wheel (page 14-20)
- Front fender (page 3-19)

Adjust the pre-load and compression/rebound damping adjusters (page 4-37).

