



Apply a locking agent to the reservoir hose joint screw threads.
Install and tighten the screw to the specified torque.

TORQUE: 1 N·m (0.15 kgf·m , 1.1 lbf·ft)



Connect the brake pedal to the push rod lower joint. Install the joint pin and secure it with a new cotter pin.



Install the main footpeg holder and tighten the mounting bolts to the specified torque.

TORQUE: 26 N·m (2.7 kgf·m , 20 lbf·ft)

Install and tighten the exhaust pipe mounting nut.

Tighten the rear master cylinder mounting bolts to the specified torque.

TORQUE: 12 N·m (1.2 kgf·m , 9 lbf·ft)



Install the brake hose eyelet joints with the oil bolt and new sealing washers.

Push the eyelet joints against the stopper, then tighten the oil bolt to the specified torque.

TORQUE: 34 N·m (3.5 kgf·m , 25 lbf·ft)



Fill the reservoir to the upper level and bleed the pedal brake line (page 15-7).